
USB Driver

Installation Procedure Manual

Supported Models: PHC-D08
 PHE-3FB2
 PHE-3FB3

Supported OS: Windows 7 (32bit, 64bit)
 Windows 8(32bit, 64bit)
 Windows 8.1(32bit, 64bit)
 Windows 10(32bit, 64bit)
 Windows Server 2008 R2
 Windows Server 2012
 Windows Server 2012 R2

<Regarding Trademarks and Licenses>

Microsoft Windows is a registered trademark of the Microsoft Corporation in the U.S. and other countries.

Windows 7, Windows 8, Windows 8.1, Windows 10, Windows Server 2008 R2, Windows Server 2012, Windows Server 2012 R2 are registered trademarks of the Microsoft Corporation in the U.S. and other countries.

The company and product names indicated in this manual are trademarks and registered trademarks of each company.


Table of Contents

1. Windows 7	3
1. Driver Installation	3
2. Connecting the Product	5
3. Driver Uninstallation.....	7
2. Windows 8, Windows 8.1	9
1. Driver Installation	9
2. Connecting the Product	11
3. Driver Uninstallation.....	13
3. Windows 10	15
1. Driver Installation	15
2. Connecting the Product	17
3. Driver Uninstallation.....	19
4. Windows Server 2008 R2	22
1. Driver Installation	22
2. Connecting the Product	24
3. Driver Uninstallation.....	26
5. Windows Server 2012, Windows Server 2012 R2	28
1. Driver Installation	28
2. Connecting the Product	30
3. Driver Uninstallation.....	32


1. Windows 7

1. Driver Installation


1. Download and extract the “Setup.bat” file in an arbitrary folder, such as “My Document”, and double-click the file.




2. If a screen displays a message, “User Account Control”, click “YES” to continue.




3. Click “Next” to continue.



4. The driver installation is started with an Installation Wizard.



5. If a Windows Security window is prompted, click "Install" to continue.



6. Click "Finish" to complete the installation.




The driver installation is completed.

By installing this driver, the USB port is managed as a virtual COM port, therefore can be controlled the same as an RS-232C port.


2. Connecting the Product

1. Connect a personal computer to this product with a USB cable.

A dialog window will pop-up after connection.




2. After awhile, "Device driver software installed successfully." will be displayed.




3. Click "Hardware and Sound" in the "Control Panel" when connecting the equipment. (View the Control Panel as a "category")



4. Click the "Device Manager" under the "Devices and Printers" section.




5. In the Ports (COM and LPT), the “USB Serial Port/PHC-D08 (COM*)” should be displayed.
(For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)
* The “(COM*)” is the number to use at the end of the command to control the equipment.




Connection of the product is complete.

3. Driver Uninstallation


1. Click “Hardware and Sound” in the “Control Panel” when connecting the equipment. (View the Control Panel as a “category”)



2. Click the “Device Manager” under the “Devices and Printers” section.




3. Check that the “USB Serial Port/PHC-D08 (COM*)” is displayed.



* Make sure the connected product model is displayed after the “USB Serial Port/” prefix. (For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)

4. Right-click on the “USB Serial Port/****” and click “Uninstall” to delete.



5. Put a check in the box for “Delete the driver software for this device”, then click “OK” to continue.




Driver Uninstallation is completed.


2. Windows 8. Windows 8.1

1. Driver Installation

1. Download and extract the “Setup.bat” file in an arbitrary folder, such as “My Document”, and double-click the file.



2. If a screen displays a message, “User Account Control”, click “YES” to continue.




3. Click “Next” to continue.



4. The driver installation is started with an Installation Wizard.



5. If a Windows Security window is prompted, click “Install” to continue.



6. Click “Finish” to complete the installation.




The driver installation is completed.


By installing this driver, the USB port is managed as a virtual COM port, therefore can be controlled the same as an RS-232C port.

2. Connecting the Product


1. Connect a personal computer to this product with a USB cable.
Connection to the device will be set up automatically.




2. Click “Hardware and Sound” in the “Control Panel” when connecting the equipment. (View the Control Panel as a “category”)



3. Click the “Device Manager” under the “Devices and Printers” section.




4. In the Ports (COM and LPT), the “USB Serial Port/PHC-D08 (COM*)” should be displayed.
(For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)
- * The “(COM*)” is the number to use at the end of the command to control the equipment.




Connection of the product is complete.

3. Driver Uninstallation


1. Click “Hardware and Sound” in the “Control Panel” when connecting the equipment. (View the Control Panel as a “category”)



2. Click the “Device Manager” under the “Devices and Printers” section.




3. Check that the “USB Serial Port/PHC-D08 (COM*)” is displayed.



(For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)
* Make sure the connected product model is displayed after the “USB Serial Port/” prefix.

4. Right-click on the “USB Serial Port/****” and click “Uninstall” to delete.



5. Put a check in the box for “Delete the driver software for this device”, then click “OK” to continue.




Driver Uninstallation is completed.


3. Windows 10

1. Driver Installation


1. Download and extract the “Setup.bat” file in an arbitrary folder, such as “My Document”, and double-click the file.




2. If a screen displays a message, “User Account Control”, click “YES” to continue.




3. Click “Next” to continue.




4. The driver installation is started with an Installation Wizard.



5. If a Windows Security window is prompted, click "Install" to continue.



6. Click "Finish" to complete the installation.




The driver installation is completed.


By installing this driver, the USB port is managed as a virtual COM port, therefore can be controlled the same as an RS-232C port.

2. Connecting the Product


1. Connect a personal computer to this product with a USB cable.
Connection to the device will be set up automatically.




2. Click “Hardware and Sound” in the “Control Panel” when connecting the equipment. (View the Control Panel as a “category”)



3. Click the “Device Manager” under the “Devices and Printers” section.




4. In the Ports (COM and LPT), the “USB Serial Port/PHC-D08 (COM*)” should be displayed.
(For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)
- * The “(COM*)” is the number to use at the end of the command to control the equipment.




Connection of the product is complete.

3. Driver Uninstallation


1. Click “Hardware and Sound” in the “Control Panel” when connecting the equipment. (View the Control Panel as a “category”)



2. Click the “Device Manager” under the “Devices and Printers” section.




3. Check that the “USB Serial Port/PHC-D08 (COM*)” is displayed.




* Make sure the connected product model is displayed after the “USB Serial Port/” prefix.
(For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)

4. Right-click on the “USB Serial Port/****” and click “Uninstall” to delete.



5. Put a check in the box for “Delete the driver software for this device”, then click “OK” to continue.




Driver Uninstallation is completed.

4. Windows Server 2008 R2

1. Driver Installation


1. Download and extract the “Setup.bat” file in an arbitrary folder, such as “My Document”, and double-click the file.




2. Click “Next” to continue.



3. The driver installation is started with an Installation Wizard.



4. When the “Windows Security” is displayed, click “Install this driver software anyway” to continue.



5. Click “Finish” to complete the installation.



The driver installation is completed.


By installing this driver, the USB port is managed as a virtual COM port, therefore can be controlled the same as an RS-232C port.

2. Connecting the Product


1. Connect a personal computer to this product with a USB cable.
A dialog window will pop-up after connection.




2. After awhile, "Device driver software installed successfully." will be displayed.



3. Click "Hardware" in the "Control Panel" when connecting the equipment. (View the Control Panel as a "category")




4. Click the "Device Manager" under the "Devices and Printers" section.



5. In the Ports (COM and LPT), the “USB Serial Port/PHC-D08 (COM*)” should be displayed.
(For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)


* The “(COM*)” is the number to use at the end of the command to control the equipment.




Connection of the product is complete.

3. Driver Uninstallation


1. Click “Hardware” in the “Control Panel” when connecting the equipment. (View the Control Panel as a “category”)



2. Click the “Device Manager” under the “Devices and Printers” section.




3. Check that the “USB Serial Port/PHC-D08 (COM*)” is displayed.



* Make sure the connected product model is displayed after the “USB Serial Port/” prefix.

4. Right-click on the “USB Serial Port/****” and click “Uninstall” to delete.



5. Put a check in the box for “Delete the driver software for this device”, then click “OK” to continue.




Driver Uninstallation is completed.

5. Windows Server 2012, Windows Server 2012 R2

1. Driver Installation

1. Download and extract the “Setup.bat” file in an arbitrary folder, such as “My Document”, and double-click the file.




2. Click “Next” to continue.



3. The driver installation is started with an Installation Wizard.



4. If a Windows Security window is prompted, click "Install" to continue.



5. Click "Finish" to complete the installation.




The driver installation is completed.


By installing this driver, the USB port is managed as a virtual COM port, therefore can be controlled the same as an RS-232C port.

2. Connecting the Product


1. Connect a personal computer to this product with a USB cable.
Connection to the device will be set up automatically.




2. Click “Hardware” in the “Control Panel” when connecting the equipment. (View the Control Panel as a “category”)



3. Click the “Device Manager” under the “Devices and Printers” section.




4. In the Ports (COM and LPT), the “USB Serial Port/PHC-D08 (COM*)” should be displayed.
(For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)
- * The “(COM*)” is the number to use at the end of the command to control the equipment.




Connection of the product is complete.

3. Driver Uninstallation


1. Click “Hardware” in the “Control Panel” when connecting the equipment. (View the Control Panel as a “category”)



2. Click the “Device Manager” under the “Devices and Printers” section.




3. Check that the “USB Serial Port/PHC-D08 (COM*)” is displayed.




* Make sure the connected product model is displayed after the “USB Serial Port/” prefix. (For the PHE-3FB2,PHE-3FB3 Model, “USB Serial Port/PHE-3FB2 (COM*)” should be displayed)

4. Right-click on the “USB Serial Port/*****” and click “Uninstall” to delete.



5. Put a check in the box for “Delete the driver software for this device”, then click “OK” to continue.



Driver Uninstallation is completed.

PATLITE Corporation

G2G

PATLITE Corporation ※Head office ■<http://www.patlite.com/>
4-1-3, Kyutaromachi, Chuo-ku, Osaka 541-0056 Japan

PATLITE (U.S.A.) Corporation ■<http://www.patlite.com/>

PATLITE Europe GmbH ※Germany ■<http://www.patlite.eu/>

PATLITE (SINGAPORE) PTE LTD ■<http://www.patlite.com/>

PATLITE (CHINA) Corporation ■<http://www.patlite.cn/>

PATLITE KOREA CO., LTD. ■<http://www.patlite.co.kr/>

PATLITE TAIWAN CO., LTD. ■<http://www.patlite.tw/>

PATLITE (THAILAND) CO., LTD. ■<http://www.patlite.co.th/>